

# EXODUS<sup>TM</sup> DYNAMIC ONE BOX SOLUTION MAINTAINED LED DYNAMIC EXIT LIGHT

Dynamic Exit Lights provide positive enforcement (flashing green LEDs) to indicate a safe exit path or negative enforcement (flashing red LEDs) to indicate that the path should be avoided due to a hazard.

It is triggered from a fire panel and provides instant visual indication on whether the exit path is safe to allow for efficient and safe egress out of large buildings such as offices, shopping centers, hospitals, high rise apartment buildings and commercial buildings.





### **Technical Specifications**

Item	Part Number	EXS-DYNAMIC/X	EXS-DYNAMIC/R	EXS-DYNAMIC/L		
	Description <b>n</b>	LED One Box Solution Wall / Ceiling Surface Mounted Dynamic Exit Light c/w Synthium™ Battery				
Input	Voltage & Frequency	230VAC ; 50Hz				
	Installation	Large terminal block and 20mm <sup>2</sup> cable entry				
	Signal (Alarm Panel)	24VDC				
Output	Light Source	High uniformity LED bar, 100,000 hours				
	Mode of Operation	Maintained, Dynamic Pictograph				
	Power Consumption	2W (standby)				
	Emergency Duration	> 120 minutes				
Controls	Charger	Intelligent 3-stage charger with Synthium™ battery management system				
	Protection	Overcharge, low voltage disconnect, overcurrent, short circuit				
	Testing Facility	Manual test switch				
	Indicators	Battery charger green LED				
Physical	Dynamic Pictograph	Straight Ahead / Red 'X'	Green Arrow Right / Red 'X'	Green Arrow Left / Red 'X'		
	Construction	Flame-retardant polycarbonate, steel FastFit™ bracket Surface mounted - wall or ceiling				
	Mounting	380mm x 75mm x 215mm				
	Dimensions L x W x H	IP20				
	IP Rating	1.5kg				
	Weight					
Environment	Operating Temperature	1° to 40°C				
	<b>Relative Humidity</b>	0 to 95%				
Compliance	Standards	RCM / EMC, AS/NZS 2293, AS/NZS 60598.1				
	AS/NZS 2293 Classification	C0 D4 C90 D8				
Accessories	STAR <sup>™</sup> Self-Test and Reporting	P/N: EXS-DYNAMIC/X/ST	EXS-DYNAMIC/R/ST	EXS-DYNAMIC/L/ST		
	DALI-compatible	P/N: EXS-DYNAMIC/X/DL	exs-dynamic/r/dl	exs-dynamic/l/dl		
	SYNECTIX <sup>™</sup> RF Wireless	P/N: EXS-DYNAMIC/X/RF	EXS-DYNAMIC/R/RF	EXS-DYNAMIC/L/RF		
	Replacement Battery	P/N: BAT-FIT: Synthium™ LiFePO₄				

NOTE: Product specifications subject to change without prior notice due to ongoing product improvement policy and changes to industry standards.

#### **Dimensions**





## AS/NZS 2293.1:2018 Spacing Table This product performs the dual role as an 24m Exit Sign and an Emergency

luminaire with the following NATA-accredited emergency classifications:

SPACING TABLE	MOUN	MOUNTING HEIGHT (m)				
NATA Classification	2.1	2.4	2.7	3.0*		
C0 - D4	7.1	7.2	7.3	7.3		
C90 - D8	9.4	9.7	9.9	10.1		
* Maximum mounting height allowed is 2 7m but for exceptions see AS2293 1 2018						

10V/ Advanced Exit & Emergency Lighting

#### **Distributed By:**





(): www.synnovate.com.au

🔀 : hello@synnovate.com.au