


EXODUS™ AQUA65

WEATHERPROOF IP65 - WALL / CEILING
MAINTAINED LED EXIT LIGHT

A versatile all-in-one weatherproof IP65 LED Exit Light meticulously designed to protect against water and dust without compromising clarity and reliability in outdoor applications and wet environments.

Comes complete with a wall or ceiling mountable bracket for single or double sided Exit lighting and is perfect for outdoor spaces, corridors, car parks, construction sites, swimming centres and cool rooms.



Available as:



SYNTHIUM™ nanotechnology is an advanced environmentally sustainable energy development that offers extended battery life, low cost of ownership, enhanced performance and improved safety.




Technical Specifications

Item	Part Number	EXS-AQUA65
	Description	LED Weatherproof IP65 Wall / Ceiling Mount 24m Exit Light c/w <i>Synthium™</i> Battery
Input	Voltage & Frequency	230VAC ; 50Hz
	Installation	Large terminal block and 20mm ² cable entry
Output	Light Source	High performance LED bar, 100,000 hours
	Mode of Operation	Maintained
	Power Consumption	2W (standby)
	Emergency Duration	> 120 minutes
Controls	Charger	Intelligent 3-stage charger with <i>Synthium™</i> battery management system
	Protection	Overcharge, low voltage disconnect, overcurrent, short circuit
	Testing Facility	Manual test switch
	Indicators	Battery charger green LED
Physical	Battery	<i>Synthium™</i> Lithium Iron Phosphate - 10 year design life
	Diffuser	All variations of Running Man pictogram
	Construction	Flame-retardant polycarbonate
	Mounting	Surface mounted - wall or ceiling (single or double side application)
	Dimensions L x W x H	415mm x 230mm x 75mm
	IP / IK Rating	IP65 / IK10
	Weight	2.5kg
Environment	Operating Temperature	1° to 40°C
	Relative Humidity	0 to 95%
Compliance	Standards	RCM / EMC, AS/NZS 2293, AS/NZS 60598.1
	AS/NZS 2293 Classification	C0 D6.3 C90 D3.2
Accessories	STAR™ Self-Test and Reporting	P/N: EXS-AQUA65/ST
	DALI-compatible	P/N: EXS-AQUA65/DL
	SYNECTIX™ RF Wireless	P/N: EXS-AQUA65/RF
	Replacement Battery	P/N: BAT-BLADE: <i>Synthium™</i> LiFePO ₄

NOTE: Product specifications subject to change without prior notice due to ongoing product improvement policy and changes to industry standards.

Dimensions



AS/NZS 2293.1:2018 Spacing Table

This product performs the dual role as an 24m Exit Sign and an Emergency luminaire with the following NATA-accredited emergency classifications:

SPACING TABLE		MOUNTING HEIGHT (m)			
NATA Classification		2.1	2.4	2.7	3.0*
EXS-AQUA65	C0 - D6.3	8.5	8.8	8.9	9.1
	C90 - D3.2	6.5	6.5	6.5	6.5

* Maximum mounting height allowed is 2.7m but for exceptions see AS2293.1 2018

Distributed By:

